




KY573 SOFA BED

Thank you for your purchase. The following care instructions will allow you to make the most of your sofa bed; helping to prolong the look and life of it by preventing wear and damage.

IMPORTANT INFORMATION

PLEASE ENSURE YOU READ THIS LEAFLET BEFORE USING YOUR SOFA BED. DO NOT DISCARD OF ANY PACKAGING UNTIL YOU HAVE CHECKED THE PRODUCT THOROUGHLY.

CARING FOR YOUR SOFA BED

- Pre-brush fabric with a soft brush and then gently vacuum.
- Plump any accent/removable cushions regularly to prevent them becoming mis-shaped or flat.
- Use a microfibre cloth to remove dust from wooden surfaces.
- In the event of a spill or stain, use specialist upholstery cleaner or cleaning services.




SUNLIGHT AND HEAT DAMAGE

- Avoid contact with direct sunlight. If needed, move items or change their position to avoid the same area being exposed to repeated sunlight/heat.
- Do not place your sofa bed close to fire places and/or radiators.
- Hot objects such as mugs/plates can permanently mark the fabric and wood, avoid placing these on the sofa bed.

SAFETY WARNINGS


- Do not allow children or pets to climb or jump on the sofa bed.
- Avoid contact with sharp objects such as buckles, toys and jewellery as these can easily snag, tear and/or pull the fabric.
- Avoid the risk of entrapment by using the sofa bed as intended; sitting facing forward on the seat.
- Keep small parts away and out of reach of children and pets.
- Do not allow children to operate the sofa bed mechanism.

PARTS LIST

IMAGE	NAME	PART	QTY	IMAGE	NAME	PART	QTY
	Seat Section	A	1		Screw	I	7
	Arm	B	2		Half Moon Washer	J	2
	Support Leg	C	1		Washer	K	10
	Front Support Rail (wooden part)	D	1		Nut	L	6
	Back Support Rail (metal part)	E	1		Spanner	M	1
	Double-ended Bolt	F	4		Allen Key	N	1
	All-thread Bolt	G	2		Screw Driver	O	1
	Bolt	H	4				


USING YOUR SOFA BED

FROM SOFA TO BED: Unzip the back and drop down the support legs before converting to a sofa bed. Hold the back of the sofa and tilt forward towards seat until you hear **ONE** click. Gently tilt the back into the bed position.



FROM BED TO SOFA

Lift the back until you hear **ONE** click to place it in a recliner position.
Lift the back until you hear **TWO** clicks for the fully upright sofa position.




ASSEMBLY INSTRUCTIONS

Unpack your sofa bed and check that all the parts on the Parts List are present. If any are missing, please contact the retailer from whom you purchased the product.

We would advise having 2 people to assemble the product.


STEP 1

Assemble your sofa bed on a flat and soft surface to prevent any damage. Attach Double-ended Bolt(F) and All-thread Bolt(G) to Arm(B) as shown in the below images.



STEP 2


Attach either side of the Arms(B) to the Seat Section(A) with Washer(K) and Nut(L) using the Spanner(M).



STEP 3

Connect the Front Support Rail(D) to the Arm(B) with the Half Moon Washer(J), Washer(K) and Nut(L) using the Spanner(M) as shown below. Connect the Back Support Rail(E) to the Arm(B) with Washer(K) and Bolt(H) using the Allen Key(N).

NOTE: Do not fully tighten the nuts until all components are assembled to allow for adjustments during assembly.




STEP 4

Attach the other side of Arms(B) to the Seat Section(A) with Washer(K) and Nut(L) using the Spanner(M).

Repeat all steps in STEP3.

Connect the Front Support Rail(D) to the Arm(B) with the Half Moon Washer(J), Washer(K) and Nut(L) using the Spanner(M) as shown below. Connect the Back Support Rail(E) to the Arm(B) with Washer(K) and Bolt(H) using the Allen Key(N).

NOTE: Do not fully tighten the nuts until all components are assembled, to allow for adjustments during assembly,



STEP 5

After confirming that all components in Step 3 and Step 4 have been assembled, tighten all nuts securely.

Then secure the Support Rail(D&E) with the Screw(I) using the Screw Driver(O).

Attach the Support Leg(C) as shown below, and close the zipper.

